THIS APPLIANCE IS MANUFACTURED BY:

SAMSUNG

AH68-01853B

SAMSUNG

Digital Surround AV Receiver System

HT-AS610

Instruction Manual

(AV-R610)

Safety Warnings

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
PRODUCTO LASER CLASE 1

CAUTION
RISK OF ELECTRIC SHOCK.
DO NOT OPEN

CAUTION:
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE REAR COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION-INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

This symbol indicates that dangerous voltage which can cause electric shock is present inside this unit.

This symbol alerts you to important operating and maintenance instructions accompanying the unit.

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

Wiring the Main Power Supply Plug(UK Only)

IMPORTANT NOTICE

The main lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug and if it requires replacing, a fuse approved to BS1362 of the same rating must be used.
Never use the plug with the fuse cover removed. If the cover is detachable and a replacement is required, it must be of the same colour as the fuse fitted in the plug. Replacement covers are available from your dealer.
If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your dealer for assistance.
However, if there is no alternative to cutting off the plug, remove the fuse and then safely dispose of the plug. Do not connect the plug to a main socket as there is a risk of shock hazard from the bared flexible cord.
Never attempt to insert bare wires directly into a main socket. A plug and fuse must be used at all times.

IMPORTANT

The wires in the main lead are coloured in accordance with the following code:–

BLUE = NEUTRAL BROWN = LIVE

As these colors may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows:–
The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLUE or BLACK. The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured BROWN or RED.

WARNING: DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL WHICH IS MARKED WITH THE LETTER E OR BY THE EARTH SYMBOL ⏚, OR COLOURED GREEN OR GREEN AND YELLOW.

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.
To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.
Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
Business users should contact their supplier and check the terms and conditions of the purchase contract.
This product should not be mixed with other commercial wastes for disposal.



Precautions





Ensure that the AC power supply in your house complies with the identification sticker located on the back of your player. Install your player horizontally, on a suitable base (furniture), with enough space around it for ventilation (7.5~10cm). Make sure the ventilation slots are not covered. Do not stack anything on top of the player. Do not place the player on amplifiers or other equipment which may become hot. Before moving the player, ensure the disc tray is empty. This player is designed for continuous use. Switching off the DVD player to the stand-by mode does not disconnect the electrical supply. In order to disconnect the player completely from the power supply, remove the main plug from the wall outlet, especially when left unused for a long period of time.



During thunderstorms, disconnect AC main plug from the wall outlet.
Voltage peaks due to lightning could damage the unit.



Do not expose the unit to direct sunlight or other heat sources.
This could lead to overheating and malfunction of the unit.



Protect the player from moisture(i.e. vases) , and excess heat(e.g.fireplace) or equipment creating strong magnetic or electric fields (i.e.speakers...). Disconnect the power cable from the AC supply if the player malfunctions. Your player is not intended for industrial use.

Use of this product is for personal use only.

Condensation may occur if your player or disc have been stored in cold temperatures.

If transporting the player during the winter, wait approximately 2 hours until the unit has reached room temperature before using.



The battery used with this product contain chemicals that are harmful to the environment.

Do not dispose of batteries in the general household trash.

Features

Digital AV Receiver

This product is a pure digital AV receiver that performs digital signal processing to minimize signal distortion and loss.

Dolby Pro Logic II

Dolby Pro Logic II is a new form of multi-channel audio signal decoding technology that improves upon existing Dolby Pro Logic.

DTS (Digital Theater Systems)

DTS play backs 5.1 channel sound with less compression than Dolby Digital for richer sound.

SFE(Sound Field Effect) Using 24bit Audio DSP

Provides more realistic surround sound with normal stereo audio sources.

Contents

PREPARATION
Safety Warnings 2
Precautions 3
Features 4
Description 6

CONNECTIONS
Connecting the Speakers 10
Connecting External Components 12
Connecting the FM and AM Antennas 15

OPERATION
Before Using the AV Receiver 16
Selecting Digital/Analog Input 18
Setting the Speaker Mode 20
Setting the Speaker Listening Distance 22
Setting Digital Input 24
Setting DRC (Dynamic Range Compression) 25
Test Tone 26
Setting Speaker Level 28
Dolby Pro Logic II Mode 30
Dolby Pro Logic II Effect 32
SFE Mode 34
Stereo Mode 36

RADIO OPERATION
Listening to Radio 38
Presetting Radio Stations 39
About RDS broadcasting 40

MISCELLANEOUS
Convenient Functions 42
Operating TV with Remote Control 44
Operating your VCR (DVD) with Remote Control 46
Before Calling for Service 48
Specifications 50

Description

[Front Panel]



[Rear Panel]



[Display]





▶▶ Accessories ◀◀


Remote Control

AM Antenna

FM Antenna


User's Manual

Description

[Remote Control]



Insert Remote Batteries

1 Remove the battery cover in the direction of the arrow.



2 Insert two 1.5V AAA batteries, paying attention to the correct polarities (+ and –).



3 Replace the battery cover.



Note

Follow these precautions to avoid leaking or cracking batteries:

- Place batteries in the remote control so they match the polarity:(+) to (+)and (–)to (–).
- Use the correct type of batteries.Batteries that look similar may differ in voltage.
- Always replace both batteries at the same time.
- Do not expose batteries to heat or flame.

Range of Operation of the Remote Control

The remote control can be used up to approximately 23 feet/7 meters in a straight line. It can also be operated at a horizontal angle of up to 30° from the remote control sensor.



Connecting the Speakers

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.



Position of AV Receiver

- Place AV Receiver on a dedicated stand or rack.

Front Speakers L R

- Place these speakers in front of your listening position, facing inwards (about 45°) toward you.
- Place the speakers so that their tweeters will be at the same height as your ear.
- Align the front face of the front speakers with the front face of the center speaker or place them slightly in front of the center speakers.

Center Speaker C

- It is best to install it at the same height as the front speakers.
- You can also install it directly over or under the TV.

Surround Speakers SL SR

- Place these speakers behind your listening position.
- If there isn't enough room, place these speakers so they face each other.
- Place them about 60 to 90cm (2 to 3feet) above your ear, facing slightly downward.

✵ Unlike the front and center speakers, the surround speakers are used to handle mainly sound effects and sound will not come from them all the time.

Subwoofer SW

- The position of the subwoofer is not so critical. Place it anywhere you like.

Note

- When you attach the speakers to a wall, make sure to fasten them tightly so they do not fall off.



SYSTEM MODEL NAME : HT-AS610

MAIN UNIT	AV-R610
FRONT SPEAKER	PS-AF610
CENTER SPEAKER	PS-AC610
SURROUND SPEAKER	PS-AR610
PASSIVE SUB WOOFER	PS-AW610

▶ Connecting Speaker Wire

1 Press the tab of the speaker connector.



2 Insert the black wire into the black(-) terminal and the gray wire into the red(+) terminal.



Caution

- Keep the subwoofer speaker out of reach of children so as to prevent children from inserting their hands or alien substances into the duct (hole) of the subwoofer speaker.
- Do not hang on the wall through the duct (hole).

Note

- Never touch speaker terminals while the power is on. Doing so could result in electric shock.
- Make sure the polarities (+ and -) are correct.

Connecting External Components

Connecting Video Component

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.



Note

- Disconnect the power plug from the outlet if you will not use this unit for a long period of time.
- In a DVD/CD player, you can select one digital audio input from OPTICAL and COAXIAL.



Note

- If using VCR, connect Analog Audio Out to VCR/SAT Audio In on this unit. If using STB, connect Digital Out to the SAT Optical connector on this unit.
- The Analog Audio and Video In jacks of the main unit are used for SAT and VCR. You cannot connect both devices at the same time.
- If there is a Digital Out for the satellite/cable STB, it can be connected to the SAT Optical connector on the rear panel to provide multi-channel surround. If there is no Digital Out connector on the STB, connect the Analog Audio Out connector to the VCR/SAT Audio In on the unit.
- If the external component has only one Audio Output jack, connect it to either the right or left Audio Input jack of the main unit.
- Connect the audio cable's red plug to the red jack and white cable to the white jack.

Connecting External Components

Connecting Audio Component

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.



Connecting the FM and AM Antennas



FM antenna connection

1. Connect the FM antenna supplied to the FM 75 COAXIAL terminal as a temporary measure.
2. Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.

AM antenna connection

1. Connect the AM loop antenna supplied to the AM and terminals.
2. If reception is poor, connect an outdoor single vinyl-covered wire to the AM terminal. (Keep the AM loop antenna connected).

COOLING FAN

The cooling fan dissipates the heat generated inside the unit so that the unit can be operated normally. The cooling fan is activated automatically to supply cool air to the unit.



Please observe the following cautions for your safety.

- Make sure the unit is well-ventilated. If the unit has poor ventilation, the temperature inside may rise and cause damage to it.
- Do not obstruct the cooling fan or ventilation holes. (If the cooling fan or ventilation holes are covered with a newspaper or cloth, heat may build up inside the unit and fire may result.)

Before Using the AV Receiver



Turning On/Off

REMOTE CONTROL

Press the **POWER** button of the remote control.

• This unit will be turned on or set to Standby mode.

MAIN UNIT

1 Connect the power plug to the outlet.

2 Press the **POWER** button of the main unit.

• This unit will be turned on or set to Standby mode.

Functions of Dedicated Remote Control

You can operate your AMP, TV, DVD, VCR with one remote control.
See pages 44-47 for more details.



To Select the Function

REMOTE CONTROL

Method 1

Press the **FUNCTION** button.

• Each time you press the this button, **FM → AM → DVD → VCR/SAT → CD** will be selected in turn.

Method 2

Press CD, VCR/SAT, DVD or TUNER button.

• You can directly select CD, VCR/SAT, DVD or TUNER.

MAIN UNIT

Press **FUNCTION** button.

• Each time you press the this button, **FM → AM → DVD → VCR/SAT → CD** will be selected in turn.

Selecting Digital/Analog Input

You can listen to sound in Analog 2 Channels or Dolby Digital 5.1 Channel using this unit.



REMOTE CONTROL

For DVD Function

Press the **INPUT MODE DIGITAL** button.

• DVD OPTICAL or COAXIAL will be selected.

or

Press the **INPUT MODE ANALOG** button.

• DVD ANALOG will be selected.

For CD Function

Press the **INPUT MODE DIGITAL** button.

• CD OPTICAL or COAXIAL will be selected.

or

Press the **INPUT MODE ANALOG** button.

• CD ANALOG will be selected.

MAIN UNIT

For DVD Function

Press the **INPUT MODE** button.

• DVD OPTICAL or COAXIAL and DVD ANALOG will be selected repetitively.

For CD Function

Press the **INPUT MODE** button.

• CD OPTICAL or COAXIAL and CD ANALOG will be selected repetitively.

Note

- You can enjoy Dolby Digital only if you connect the Digital Audio Output jack of an external audio component to the optical/coaxial Digital Audio Input jack on the main unit.
- The digital input mode is set to either OPTICAL or COAXIAL, depending on the setting of <SETUP> → <DIGITAL IN>.

Setting the Speaker Mode

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.
Frequency response from the speaker will be adjusted according to your speaker configuration and whether certain speakers are used or not.

REMOTE CONTROL

1 Press **SPK SELECT** button to select the speaker you want.
- Each time you press this button, F.SPK → C.SPK → S.SPK → SW SPK → CROVR → SPK MODE OFF will be selected in turn.

2 Press ▲▼ button to set the speaker mode.

To Exit Setup Mode
- Wait for about 5 seconds or press the **SPK SELECT** button of the remote control to select SPK MODE OFF.



MAIN UNIT

1 Press **SETUP** button.
- "SETUP MODE" appears on the display and enters into Setup Mode.

2 Press **FUNCTION** button 1 time.
- "SPK SETUP" appears in the display.

3 Press **SURROUND** button to select the speaker you want.
- Each time you press this button, F.SPK → C.SPK → S.SPK → SW SPK → CROVR will be selected in turn.

4 Press **SELECT** (∨, ∧) button to set the speaker mode.

To Exit Setup Mode
- Wait for about 5 seconds or press **SETUP** button.
  "SETUP MODE OFF" appears on the display and exits Setup Mode.

To turn the SUBWOOFER On or Off.
Press **SUBWOOFER** button.
- Each time you press this button, SW SPK : YES, SW SPK : NO will be selected in turn.
- If you play in 2 Channel Stereo, select 'YES' to use Subwoofer and 'NO' not to use.

Note
- If F.SPK is set to 'SMALL', SW SPK is automatically set to 'YES'.

Setting the Speaker

- **F.SPK (Front)** : LARGE, SMALL
- **C.SPK (Center)** : LARGE, SMALL, NONE
- **S.SPK (Surround)** : LARGE, SMALL, NONE
- **SW SPK (Subwoofer)** : YES, NO
- **CROVR (Crossover Frequency)** : 60, 80, 100, 120, 150, 180, 200Hz

- **LARGE** : Select when you use large speaker. You can listen to full range sound.
- **SMALL** : Select this when you use small speaker. Bass below 100Hz will not be output.
- **NONE** : Select this when you use no speaker.
- **YES(Subwoofer)** : Select this when you use Subwoofer Speaker.
- **NO(Subwoofer)** : Select when you do not use Subwoofer Speaker.
- **CROVR**: Select the crossover frequency for the best bass response in your room.

Setting the Speaker Listening Distance



REMOTE CONTROL

1 Press the **SPK DISTANCE** button to select the speaker you want.

- Each time you press this button, F.L → CEN → F.R → S.R → S.L → S.W → DIST OFF will be selected in turn.

2 Press ▲▼ button to set the speaker distance.

- For F.L, CEN, F.R, S.W, S.R, S.L Speaker, you can set the distance from the speaker to listening position between 0.3~9.0m in intervals of 0.3m.

To Exit Setup Mode

- Wait for about 5 seconds or press the **SPK DISTANCE** button of remote control to select DIST OFF.

Note

- If the listening position is beyond the range of speaker distance setup when you place the speaker, set the speaker distance to the maximum.

MAIN UNIT

1 Press **SETUP** button.

- "SETUP MODE" appears on the display and enters into Setup Mode.

2 Press **FUNCTION** button 2 times.

- "DIST SETUP" appears on the display.

3 Press **SURROUND** button to select the speaker you want.

- Each time you press this button, F.L → CEN → F.R → S.R → S.L → S.W will be selected in turn.

4 Press **SELECT**(⌄,⌃) button to set the speaker distance.

- For F.L, CEN, F.R, S.W, S.R, S.L Speaker, you can set the distance from the speaker to listening position between 0.3~ 9m in intervals of 0.3m.

To Exit Setup Mode

- Wait for about 5 seconds or press **SETUP** button.
  "SETUP MODE OFF" appears on the display and exit Setup Mode.

Setting Digital Input

You can set the digital input for a DVD/CD player to either OPTICAL or COAXIAL.

MAIN UNIT

1 Press **SETUP** button.
- "SETUP MODE" appears on the display and enters into Setup Mode.

2 Press **FUNCTION** button 3 times.
- "DIGITAL IN" appears on the display.

3 Press **SURROUND** button to select the DVD or CD function.
- Each time this button, DVD ⟷ CD will be selected in turn.

4 Press **SELECT**(∨, ∧) button to set the digital input.
- Each time you press this button, OPTICAL ⟷ COAXIAL will be selected in turn.

To Exit Setup Mode

- Wait for about 5 seconds or press **SETUP** button.
  "SETUP MODE OFF" appears on the display and the unit exits Setup Mode.

Setting DRC (Dynamic Range Compression)

You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night.

REMOTE CONTROL

Press **DRC** button.
- Each time you press this button, DRC : STD → DRC : MAX → DRC : MIN will be selected in turn.

MAIN UNIT

1 Press **SETUP** button.
- "SETUP MODE" appears on the display and enters into Setup Mode.

2 Press **FUNCTION** button 4 times.
- "DRC SETUP" appears on the display.

3 Press **SURROUND** button.
- "DRC : STD" appears on the display .

4 Press **SELECT**(∨, ∧) button to set DRC.
- Each time you press this button, DRC : STD → DRC : MAX → DRC : MIN will be selected in turn.

To Exit Setup Mode

- Wait for about 5 seconds or press **SETUP** button.
  "SETUP MODE OFF" appears on the display and the unit exits Setup Mode.

Setting DRC

- **STD** : Sets DRC effect to standard.
- **MAX** : Sets DRC effect to maximum.
- **MIN** : Sets DRC effect to minimum.

Test Tone

Use test tone to check the speaker connection status or level.

To Automatically Output Test Tone

REMOTE CONTROL

Press **TEST TONE** button.

- Test signal will be automatically output as follows; F.L → CEN → F.R → S.R → S.L → S.W.
- During test tone output, press ▲▼ button to adjust the speaker output level from -10 to +10 dB by 1 step.

To Stop Test Tone

- Press **TEST TONE** button again.

MAIN UNIT

1 Press **SETUP** button.
- "SETUP MODE" appears on the display and enters into Setup Mode.

2 Press **FUNCTION** button 5 times.
- "TEST-T AUTO" appears in the display.

3 Press **SURROUND** button.
- Test signal will be automatically output as follows; F.L → CEN → F.R → S.R → S.L → S.W .
- During test signal output, press **SELECT** (∨, ∧) button to adjust the speaker output level from -10 to +10 dB by 1 step.

To Stop Test Tone

Press **SETUP** button 1 time.
- "SETUP MODE OFF" appears on the display and test tone stops.

To Manually Output Test Tone

MAIN UNIT

1 Press **SETUP** button.
- "SETUP MODE" appears on the display and the unit enters into Setup Mode.

2 Press **FUNCTION** button 6 times.
- "TEST-T MANU" appears in the display.

3 Press **SURROUND** button.
- Each time you press this button, F.L → CEN → F.R → S.R → S.L → S.W will be selected in turn.

4 Press **SELECT**(∨, ∧) button to set the test tone as you want.
- You can adjust the speaker output level from -10 to +10dB by 1 step.
- The sound gets quieter at -10dB and louder at +10dB.

To Stop Test Tone

Press **SETUP** button 1 time.
- "SETUP MODE OFF" appears on the display and test signal stops.

Test Tone Output

- **F.L (Front-Left)** : -10 ~ +10dB
- **CEN (Center)** : -10 ~ +10dB
- **F.R (Front-Right)** : -10 ~ +10dB
- **S.R (Surround-Right)** : -10 ~ +10dB
- **S.L (Surround-Left)**: -10 ~ +10dB
- **S.W (Subwoofer)**: -10 ~ +10dB

Setting Speaker Level

You can set the balance and level of speakers

Remote Control

1 Press **SPK LEVEL** button to select the speaker you want.

- Each time you press this button, F.L → CEN → F.R → S.R → S.L → S.W → SPK LVL OFF will be selected in turn.

2 Press ▲▼ button to set the speaker level you want.

- You can adjust it from -10 to +10dB by 1 step.
- The sound gets quieter at -10dB and louder at +10dB.
- Default setting value is 00dB.

To Exit Setup Mode

- Wait for about 5 seconds or press **SPK LEVEL** button on the remote control to select SPK LVL OFF.

MAIN UNIT

1 Press **SETUP** button.

- "SETUP MODE" appears on the display and enters into Setup Mode.

2 Press **FUNCTION** button 8 times.

- "LEVEL SETUP" appears on the display.

3 Press **SURROUND** button.

- Each time you press this button, F.L → CEN → F.R → S.R → S.L → S.W will be selected in turn.

4 Press **SELECT**(∨, ∧) button to set to the speaker level you want.

- You can adjust it from -10 to +10dB by 1 step.
- The sound gets smaller at -10dB and louder at +10dB.
- Default setting value is 00dB

To Exit Setup Mode

- Wait for about 5 seconds or press **SETUP** button.
  "SETUP MODE OFF" appears on the display and exits Setup Menu.

Setting Speaker Level

- **F.L (Front-Left)** : -10 ~ +10dB
- **CEN (Center)** : -10 ~ +10dB
- **F.R (Front-Right)** : -10 ~ +10dB
- **S.R (Surround-Right)** : -10 ~ +10dB
- **S.L (Surround-Left)**: -10 ~ +10dB
- **S.W (Subwoofer)**: -10 ~ +10dB

Dolby Pro Logic Ⅱ Mode

This mode provides 5.1 channel sound from 2 channel sources



REMOTE CONTROL

Press **MODE** button.

- Each time you press this button, CINEMA → MATRIX → GAME → PROLOGIC → MUSIC will be selected in turn.



To Exit Setup Mode

- Wait for about 5 seconds.



MAIN UNIT

1 Press **SURROUND** button to select "DPL Ⅱ" Mode.

- Each time you press this button, DPL Ⅱ → SFE → STEREO will be selected in turn.

2 Press **SELECT**(∨,∧) button.

- Each time you press **SELECT (∧)** button, CINEMA → MATRIX → GAME → PROLOGIC → MUSIC will be selected in turn.
- Each time you press **SELECT (∨)** button, MUSIC → PROLOGIC → GAME → MATRIX → CINEMA will be selected in turn.

To Exit Setup Mode

- Wait for about 5 seconds.

Dolby Pro Logic Ⅱ Mode

- **MUSIC** : Provides 5.1 Channel Surround sound to digital, analog or existing stereo sources such as CD, TAPE, FM, TV and Stereo VCR.
- **CINEMA** : Adds realism to the movie soundtrack.
- **MATRIX** : You will hear 5.1 Channel Surround sound.
- **GAME** : Enhances the excitement of the game's sound.
- **PROLOGIC** : You will experience a surround effect with just the front left and right speakers.

Note

- You cannot use Dolby Pro Logic Ⅱ Mode for multi channel signals such as Dolby Digital and DTS.
- Pro Logic works only for PCM audio signals with sampling frequencies of 32KHz, 44KHz or 48KHz.
- Sound will not be output from rear center speaker if PCM audio signal is mono.

Dolby Pro Logic Ⅱ Effect

This function works only in Dolby **PRO LOGIC II MUSIC** Mode.



REMOTE CONTROL

1 Press **MODE** button to select 'MUSIC' Mode.

2 Press **EFFECT** button.

- Each time you press this button, C-WIDTH → DIMENSION → PANORAMA → DPL Ⅱ EFT OFF will be selected in turn.



3 Press ▲▼ button to select Dolby Pro Logic Ⅱ effect you want.

- C-WIDTH: You can set from 0 to 7.
- DIMENSION: You can set from -7 to +7.
- PANORAMA: You can Set it ON or OFF.

To Exit Setup Mode

- Wait for about 5 seconds or press Effect button of remote control to select DLP Ⅱ EFT OFF.

MAIN UNIT

1 Press **SETUP** button.

- "SETUP MODE" appears on the display and enters into Setup Mode.

2 Press **FUNCTION** button 10 times.

- "DPL Ⅱ MODE"appears on the display.

3 Press **SURROUND** button.

- Each time you press this button, **C-WIDTH → DIMENSION → PANORAMA** will be selected in turn.

4 Press **SELECT**(∨, ∧) button to select Dolby Pro Logic Ⅱ effect you want.

To Exit Setup Mode

- Wait for about 5 seconds or press **SETUP** button.
  "SETUP MODE OFF" appears on the display and exits Setup Mode.

OPERATION

Dolby Pro Logic Ⅱx Effect

- **C-WIDTH** : This sets the width of the center image. The higher the setting, the less sound comes from the center speaker.
- **DIMENSION** : Incrementally adjusts the sound field (DSP)from the front or rear.
- **PANORAMA** : This mode extends the front stereo image to include the surround speakers for an exciting "wraparound" effect with side wall imaging.

SFE Mode

Refer to the unique sound existing at specific place and you can feel live sound as if you are listening at actual site.



REMOTE CONTROL

Press **SFE MODE** button.

- Each time you press this button, **HALL → THEATER → ARENA → CLUB → DOME → STADIUM → CHURCH** will be selected in turn.

To Exit Setup Mode

- Wait for about 5 seconds.

MAIN UNIT

1 Press **SURROUND** button to select 'SFE' Mode.

- Each time you press this button, DPL II → SFE → STEREO will be selected in turn.

2 Press **SELECT**(⌄, ⌃) button.

- Each time you press Select (⌃) button, **HALL → THEATER → ARENA → CLUB → DOME → STADIUM → CHURCH** will be selected in turn
- Each time you press Select (⌄) button, **CHURCH → STADIUM → DOME → CLUB → ARENA → THEATER → HALL** will be selected in turn.

To Exit Setup Mode

- Wait for about 5 seconds.

Stereo Mode

You can select this mode when you listen to sound through the Front Left and Right speakers and subwoofer.



REMOTE CONTROL

Press **STEREO** button.

- "STEREO" appears in the display and Stereo Mode is selected.

To Exit Setup Mode

- Wait for about 5 seconds.

MAIN UNIT

Press **SURROUND** button to select 'STEREO'.

- Each time you press this button, DPL II → SFE → STEREO will be selected in turn.

To Exit Setup Mode

- Wait for about 5 seconds.

Note

- When PCM and Analog Stereo signals are input, the left and right channels are played back in Stereo Mode.

For Surround Mode and Input Signal

o = active, – = inactive

Surround Mode	Input Signal	Decoding	Output Channel				Display Information	
			L/R	C	SL SR	Sub Woofer	Display Signal Format	Channel Status
DOLBY (MUSIC, CINEMA, MATRIX, GAME, PROLOGIC)	Dolby D Surr. EX	Dolby Digital 5.1	O	O	O	O	DIGITAL	L, C, R, SL, SR, SW
	Dolby D (5.1ch)	Dolby Digital 5.1	O	O	O	O	DIGITAL	L, C, R, SL, SR, SW
	Dolby D (2ch)	Pro Logic II	O	O	O	O	DIGITAL	L, C, R, SL, SR, SW
	Dolby D (2ch Surr)	Pro Logic II	O	O	O	O	DIGITAL	L, C, R, SL, SR, SW
	L.PCM (Audio)	Pro Logic II	O	O	O	O	L.PCM	L, C, R, SL, SR, SW
	Analogique	Pro Logic II	O	O	O	O	ANALOG	L, C, R, SL, SR, SW
DTS	DTS-ES	DTS 5.1	O	O	O	O	DTS	L, C, R, SL, SR, SW
	DTS 96/24	DTS 5.1	O	O	O	O	DTS	L, C, R, SL, SR, SW
	DTS (5.1)	DTS 5.1	O	O	O	O	DTS	L, C, R, SL, SR, SW
	L.PCM (Audio)	Neo:6	O	O	O	-	L.PCM	L, R
SFE	Dolby D (2ch)	DD + SFE	O	O	O	O	DIGITAL	L, C, R, SL, SR, SW
	Dolby D (2ch Surr)	DD + SFE	O	O	O	O	DIGITAL	L, C, R, SL, SR, SW
	L.PCM (Audio)	SFE	O	O	O	O	L.PCM	L, C, R, SL, SR, SW
	Analogique	SFE	O	O	O	O	ANALOG	L, C, R, SL, SR, SW
STEREO	Dolby D (2ch)	DD	O	-	-	-	DIGITAL	L, R, SW
	Dolby D (2ch Surr)	DD	O	-	-	-	DIGITAL	L, R, SW
	L.PCM (Audio)	Stereo	O	-	-	-	L.PCM	L, R, SW
	L.PCM 96KHz	Stereo	O	-	-	-	L.PCM	L, R, SW
	Analogique	Stereo	O	-	-	-	ANALOG	L, R, SW

L/R : Front Speaker (Left/Right) **C** : Center Speaker **SL/SR** : Rear Speaker (Left/Right) **SW** : Subwoofer

Note

- Channel status display are dependent on "Speaker Configuration".
- SFE Mode works 2ch signal.

Listening to Radio

You can listen to the chosen band (FM, AM broadcast stations) by using either the automatic or manual tuning operation.



REMOTE CONTROL

1 Press **TUNER** button.

- Each time you press this button, FM → AM will be repetitively selected.

2 Select frequency.

- Automatic Tuning 1 :
  1) Press **TUNER MODE** button to select PRESET.
  2) Press **TUNING/CH (∨, ∧)** button to select the preset frequency.
- Automatic Tuning 2 :
  1) Press **TUNER MODE** button to select MANUAL
  2) Press and hold **TUNING/CH (∨, ∧)** button to automatically tune in frequency.
- Manual Tuning :
  1) Press **TUNER MODE** button to select MANUAL.
  2) Press **TUNING/CH (∨, ∧)** button briefly to increase or decrease frequency by step by step.

MAIN UNIT

1 Press **FUNCTION** button to select FM or AM.

2 Select the frequency.

- Automatic Tuning :
  Press and hold **TUNING(∨, ∧)** button to automatically tune in frequency.
- Manual Tuning :
  Press **TUNING(∨, ∧)** button briefly to increase or decrease the frequency step by step.

To Listen to Mono/Stereo

Press **MO/ST** button on the remote.

- Each time you press this button, STEREO, MONO will be selected in turn.
- If you select MONO in the area with weak reception, it will help to reduce noise.
- This function works only with the Remote Control.

How to select MAIN UNIT, PRESET, MANUAL

1. Press the **SETUP** button.
2. Press the **FUNCTION** button 9 times.
   - "TUNER SETUP" appears in the display.
3. Press the **SURROUND** button.
4. **SELECT** (∨, ∧) button to select MANUAL or PRESET.

Presetting Radio Stations

You can preset up to 30 FM and AM stations.



REMOTE CONTROL

Ex) If you preset FM 89.10 station in 2ch

1 Press **TUNER** button.

- Each time you press this button, FM → AM will be selected in turn.



2 Press Select button and then **TUNING MODE** button to select 89.10.

- Refer to step 2, page 38, to tune in automatically and manually.

3 Press **TUNER MEMORY** button.

- Tuner number will blink on the display.

4 Press **TUNING/CH(∨, ∧)** button to select preset 2.

- You can select from presets 1 to 30.

5 Press **TUNER MEMORY** button.

- Tuner number will disappear and station 89.10 will be saved in preset 2.

6 To preset other stations, repeat steps 2 to 5.

To Listen to Preset Station

- Press **TUNING MODE** button of the remote control to select the PRESET and press **TUNING/CH (∨, ∧)** button.

RADIO OPERATION

About RDS broadcasting

Using the RDS (Radio Data System) to receive FM stations

RDS allows FM stations to send an additional signal along with their regular program signals. For example,the stations send their station names,as well as information about what type of program they broadcast, such as sports or music,etc.

When tuned to an FM station which provides the RDS service,the RDS indicator lights up on the display.

- **Description on RDS function**

1. PTY (Program Type) : Displays the type of programmer currently being broadcast
2. PS NAME (Program Service Name) : Indicates the name of broadcasting station and is composed of 8 characters.
3. RT (Radio Text) : Decodes the text broadcast by a station (if any) and is composed of maximum 64 characters.
4. CT (Clock Time) : Decodes the real time clock from the FM frequency.
 • Some stations may not transmit PTY, RT or CT information therefore this may not be displayed in all cases.
5. TA (Traffic Announcement) : When this symbol flashes it shows that the traffic announcement is in progress.

Note

• RDS may not operate correctly if the station tuned is not transmitting RDS signal properly or if the signal strength is weak.

What information can RDS signals provide?

You can see the RDS signals the station sends on the display.

TO show the RDS signals

Press RDS DISPLAY while listening to an FM station.
Each time you press the button, the display change to show you the following information:

PS NAME → RT → CT → Frequency

PS (Program Service) : While searching,"**PS**"appears and then the station names will be displayed."**NO PS**" appears if no signal is sent.
RT(RadioText) : while searching,"**RT**"appears and then text messages the station sends will be displayed. "**NO RT**"appears if no signal is sent.
Frequency : station frequency (non-RDS service)

About characters shown in the display

When the display shows PS,or RT signals,the following characters are used.

- The display window cannot differentiate upper case and lower case letters and always uses upper case letters.
- The display window cannot show accented letters, "**A**," for instance, may stands for accented "**A's**" like "**À, Â, Ã, Á, Åand Ā**."

Note

• If searching finishes at once,"**PS**",and "**RT**" will not appear on the display.



PTY (Program Type) indication and PTY-SEARCH function

One of the advantages of the RDS service is that you can locate a particular kind of program from the preset channels by specifying the PTY codes.

To search for a program using the PTY codes

Before you start, remember...

- The PTY Search is only applicable to preset stations.
- To stop searching any time during the process, press PTY SEARCH while searching.
- There is a time limit in doing the following steps. If the setting is cancelled before you finish, start from step 1 again.
- When pressing the buttons on the primary remote control, make sure that you have selected the FM station using the primary remote control.

1 Press PTY SEARCH while listening to an FM station.

2 Press the PTY-or PTY+until the PTY code you want appears on the display.
- The display gives you the PTY codes described to the right.

3 Press PTY SEARCH again, while the PTY code selected in the previous step is still on the display.
- The center unit searches 10 preset FM stations,stops when it finds the one you have selected, and tunes in that station.

Display	Program Type
NEWS	• News including an announced opinion and report
AFFAIRS	• Several matters including a current incident, documentary, discussion and analysis.
INFO	• Information including weights and measures, returns and forecast, matters interesting the customer, medical information, etc.
SPORT	• Sports
EDUCATE	• Education
DRAMA	• Drama-Radio serial, etc.
CULTURE	• Culture-National or local culture including the religious problem, social science, language, theater,etc.
SCIENCE	• Natural science and technology
VARIED	• Others-Speech, amusing program (quiz, game), interview, comedy and satirical play, etc.
POP M	• Pop music
ROCK M	• Rock music
M.O.R.M	• Current contemporary music considered to be "easy listening."
LIGHT M	• Light classical music- Classical music and instrumental and chorus music
CLASSICS	• Heavy classical music-Orchestra music, symphony, chamber music and opera
OTHER M	• Other music - Jazz, R&B country music
WEATHER	• Weather
FINANCE	• Finance
CHILDREN	• Children's programmers
SOCIAL A	• Social affairs
RELIGION	• Religion
PHONE IN	• Phone in
TRAVEL	• Travel
LEISURE	• Leisure
JAZZ	• Jazz Music
COUNTRY	• Country Music
NATION M	• National Music
OLDIES	• Oldies Music
FOLK M	• Folk Music
DOCUMENT	• Documentary

Convenient Functions



Sleep Timer Function

You can set the time that this unit will shut itself off.

REMOTE CONTROL

Press the **SLEEP** button.

• SLEEP : OFF → 15 → 30 → 45 → 60 → 90 → 120MIN will be selected in turn.

To Check Sleep Timer

Press **SLEEP** button.

• The remaining time before this unit will shut itself off is shown on the display.
• Pressing the button again changes the sleep time from what you have set earlier.

To Cancel Sleep Timer

• Press **SLEEP** button until SLEEP : OFF appears on the display.

Mute Function

This function is useful when answering a doorbell or telephone call.

REMOTE CONTROL

Press the **MUTE** button.

• **MUTE** appears on the display.

To Output Sound Again

Press **MUTE** button again.

• MUTE will disappear and sound will Output.

Note

• SLEEP, Mute and Adjust Display function can only be operated with the remote control.

Reset Function

REMOTE CONTROL

1. Press the **MUTE** button.
   • **MUTE** appears on the display.
2. Press "**0**" button five times and then press **ENTER** button.
3. Press ▲▼ buttons to select "YES".
   • The unit will turn automatically back on in 5 seconds.

Caution

• Using the RESET function will erase all stored settings.
• Do not use this unless necessary.

Adjust the Display

You can adjust the brightness of the display.

REMOTE CONTROL

Press the **DIMMER** button.

• Each time you press this, the brightness of the display will be adjusted.

Using Headphone

Use headphones (not supplied) for private listening pleasure.

Connect the headphone to the headphone jack and listen to music.

Note

• Do not turn the volume up too high when you use headphones as It may damage your hearing.

MISCELLANENOUS

Operating your TV with the Remote Control



1 Press **TV** button to set the remote to TV mode.

2 Press **POWER** button to turn on the TV.

3 Point the remote control toward the TV.

4 While holding down **POWER** button, enter the code corresponding to your brand of TV.

- If the code matches the TV's code, the TV will be turned off.
- If there is more than one code listed for your TV in the table, enter one at a time to determine which code works.

5 If TV is turned on or off when you press the power button of the remote control, the setting is completed.

- You can use the TV POWER, VOLUME, CHANNEL, MENU and Numeric buttons (0~9).

Note

- The remote control may not work on some brands of TVs. Also, some operation may not be possible depending on your brand of TV.
- The remote control will work with Samsung TVs by default.

TV Brand Code List

Brand	Code Number	Brand	Code Number	Brand	Code Number
ADMIRAL(M.WARDS)	056, 057, 058	LUXMAN	018	SYLVANIA	018, 040, 048, 054, 059, 060, 062
A MARK	001, 015	LXI(SEARS)	019, 054, 056, 059, 060, 062, 063, 065, 071	SYMPHONIC	061, 095, 096
ANAM	001, 002, 003, 004,005, 006, 007, 008, 009, 010, 011, 012, 013, 014	MAGNAVOX	015, 017, 018, 048, 054, 059, 060, 062, 072, 089	TATUNG	006
				TECHWOOD	018
AOC	001, 018, 040, 048	MARANTZ	040, 054	TEKNIKA	003, 015, 018, 025
BELL&HOWELL(M.WARDS)	057, 058, 081	MATSUI	054	TMK	018, 040
BROCSONIC	059, 060	MGA	018, 040	TOSHIBA	019, 057, 063, 071, 101 107, 109, 110, 111, 113
CANDLE	018	MITSUBISHI/MGA	018, 040, 054, 059, 060, 075, 101		
CETRONIC	003			VIDTECH	018
CITIZEN	003, 018, 025	MTC	018	VIDECH	059, 060, 069
CINEMA	097	NEC	018, 019, 020, 040, 059, 060	WARDS	015, 017, 018, 040, 048, 054, 060, 064
CLASSIC	003				
CONCERTO	018	NIKEI	003	YAMAHA	018
CONTEC	046	ONKING	003	YORK	040
CORONADO	015	ONWA	003	YUPITERU	003
CRAIG	003, 005, 061, 082, 083, 084	PANASONIC	006, 007, 008, 009, 054, 066, 067, 073, 074	ZENITH	058, 079
				ZONDA	001
CROSLEX	062	PENNEY	018	DONGYANG	003, 054
CROWN	003	PHILCO	003, 015, 017, 018, 048, 054, 059, 062, 069, 090	LOWE	054
CURTISMATES	059, 061, 063			FINLUX	054, 109, 114
CXC	003	PHILIPS	015, 017, 018, 040, 048 054, 062, 072, 112, 114, 117, 118	YOKO	054
DAEWOO	002, 003, 004, 015,016, 017, 018, 019, 020, 021, 022, 023, 024, 025, 026, 027, 028, 029, 030, 032, 034, 035, 036, 040, 048, 059, 090, 099, 100			LOEWE OPTA	054, 114
				PHONOLA	054, 112, 114
		PIONEER	063, 066, 080, 091	RADIOLA	054, 112
		PORTLAND	015, 018, 059	SCHNEIDER	054
		PROTON	040	AKAI	103
		QUASAR	006, 066, 067	GRUNDIG	108, 109, 113, 119, 120, 121
DAYTRON	040	RADIO SHACK	017, 048, 056, 060, 061, 075		
DYNASTY	003			BLAUPUNKT	108
EMERSON	003, 015, 040, 046, 059, 061, 064, 082, 083, 084, 085	RCA/PROSCAN	018, 059, 067, 076, 077 078, 092, 093, 094	SIEMENS	108
				CGE	113
		REALISTIC	003, 019	IMPERIAL	113
FISHER	019, 065, 103	SAMPO	040	MIVAR	113
FUNAI	003	SAMSUNG	000, 015, 016, 017, 040, 043, 046, 047, 048, 049, 054, 059, 060, 098	SABA	114
FUTURETECH	003			BANG&OLUFSEN	114
GENERAL ELECTRIC(GE)	006, 040, 056, 059, 066, 067, 068	SANYO	019, 061, 065, 101, 102, 103, 104	BRIONVEGA	114
				FORMENTI	114
HALL MARK	040			METZ	114
HITACHI	015, 018, 050, 059, 069	SCOTT	003, 040, 060, 061	WEGA	114
INKEL	045	SEARS	015, 018, 019	RADIOMARELLI	114
JC PENNY	056, 059, 067, 086	SHARP	015, 057, 064, 101, 105, 106, 115	SINGER	114
JVC	070			SINUDYNE	114
KTV	059, 061, 087, 088	SIGNATURE2000(M.WARDS)	057, 058	TELEFUNKEN	116
KEC	003, 015, 040	SONY	050, 051, 052, 053, 055, 101		
KMC	015				
LG(GOLDSTAR)	001, 015, 016, 017, 037, 038, 039, 040, 041, 042, 043, 044, 054, 086	SOUNDESIGN	003, 040		
		SPECTRICON	001		
		SSS	018		

Operating your DVD (VCR) with Remote Control



1 Press **DVD** button to set the remote to DVD mode.

- If you operate VCR, press VCR button to set the remote to VCR mode.

2 Press **POWER** button to turn on the DVD (VCR).

3 Point the remote control toward the DVD (VCR).

4 While holding down **POWER** button, enter the code corresponding to your brand of DVD (VCR).

- If the code matches the DVD (VCR)'s code, the DVD (VCR) will be turned off.
- If there is more than one code listed for your DVD (VCR) in the table, enter one at a time to determine which code works.

5 If DVD (VCR) is turned on or off when you press the power button of the remote controller, the setting is completed.

- You can use DVD (VCR) POWER, VOLUME, PLAY, PAUSE, STOP, SKIP, MENU and Numeric button (0~9).

Note

- The remote control may not work on some brands of DVD (VCR)s. Also, some operations may not be possible depending on your brand of DVD (VCR).
- The remote control will work with Samsung DVDs (VCRs) by default.

VCR Brand Code List

Brand	Code Number
ADMIRAL(M.WARDS)	043,106
AWIA	044,045,046
AKAI	088,089,090
ANAM	001,002,003,004,005,033
AOC	091
AUDIO DYNAMIC	019,047,092
BELL&HOWELL(M.WARDS)	048,093
BROKSONIC	092,094,095
CANON	001,033,049,091
CAPEHART	011
CITIZEN	050
CRAIG	050,072,096
CRITERION	051
CURTIS MATHES	001,031,032,033,044,091
DAEWOO	006,007,008,009,010,011,012,013,014,015,016,017,018,046,051,091
DAYTRON	011
DBX	019,047,052,092
EMERSON	025,031,032,044,046,094,095,097,098,099
FISHER	009,048,053,054,055,100
FUNAI	044
GENERAL ELECTRIC(GE)	001,031,032,033,056,091
GO VIDEO	059,060,061
HARMAN KARDON	019
HITACHI	020,021,049,054,062,100
HQ	051
INSTANT REPLAY	001,033,049,091
JCL	001,033
JCP	025
JC PENNY	047,048,052,062,091,092
JVC	001,033,047,052,063,064,065,092
KENWOOD	047,050,052,092
LG(GOLDSTAR)	019,020,021,022,023,024,025,026,027,028,029,030,050
LXI(SEARS)	020,025,044,048,050,053,054,055,062,100
MAGIN	072
MAGNAVOX	001,031,032,033,049,066,067,091
MARANTZ	001,019,033,047,052,092,110
MARTA	025,050
MEI	001,033
MEMOREX	001,025,033,054,091,100
MINOLTA	020,021,062
MITSUBISHI/MGA	068,069,070,101,102
MTC	072
MULTITECH	044,057,069
NEC	019,047,052,057,092
OLYMPIC	049,091
OPTIMUS	101
ORION	103
PANASONIC	001,004,033,049,067,091,107
PENNEY	019,020,072
PENTAX	001,020,021,033,062
PHILCO	001,033,046,049,091,094
PHILIPS	001,030,033,049,050,066,091
PILOT	025
PIONEER	049
PORTLAND	011
QUASAR	001,033,049,067,091,107,108
RICO	036
RCA/PROSCAN	001,020,021,031,032,033,049,051,062,066,070,091,104
REALISTIC	001,009,025,033,044,048,054,091,101,105
SAMSUNG	000,006,031,032,057,058,071,072,073,074,075,076,077,078,079,080,081
SANYO	008,009,046,048,050,054,058,093,100
SANSUI	092
SCOTT	006,051,054,057,069,070,100,101
SEARS	020,021,025
SHARP	043,105,106
SINGER	096
SIGNATURE 2000(M.WARDS)	043,044,054,100,106
SHINTOM	096
SONY	034,035,036,037,038,039,040,041,042,082,083,084,085,086
STS	020
SYLVANIA	001,033,044,049,066,091
SYMPHONIC	044
TANDY	009
TASHIRO	050
TATUNG	047,052,092
TEAC	044,047,052,092
TECHNICS	001,033,049,091
TEKNIKA	001,025,033
TOSHIBA	006,051
TOTEVISION	025,072
TAEKWANG	087
UNITECH	072
VECTOR RESEARCH	019
VIDEO CONCEPTS	019
VIDEOSONIC	072
WARDS	001,020,031,032,033,043,050,054,072,100,105,106,109
YAMAHA	019,047,048,052,092,
ZENITH	019,047,048,052,092

DVD Brand Code List

Brand	Code Number
DENON	003,032
DOONOON	019
DMTECH	017
FISHER	002
GE	006
HARMAN/KARDON	012
JVC	010,013
KENWOOD	008
LG	001
MAGNAVOX	004
MITSUBISHI	005,016
ONKYO	004,014
OPTIMUS	011
PANASONIC	021
PROSCAN	006
PHILIPS	004,023
PIONEER	007,011,022,025
RCA	006
SAMSUNG	000,027
SANYO	002
SONY	015, 020
THETA DIGITAL	011
TOSHIBA	004, 018
YAMAHA	009, 033
ZENITH	004, 024
TAEGWANG	026
PS2	028
X-BOX	029
APEX	030
MARANTZ	031

Before Calling for Service

Symptom	Check	Remedy
Can't turn it on.	• Is the power code plugged into the outlet?	• Connect the power plug to the outlet.
It does not work when the button is pressed.	• Is there static electricity in the air?	• Disconnect the power plug and connect it again.
Sound is not produced.	• Are the speaker and external component connected properly? • Does the Mute function work? • Is the volume set to minimum? • Is the speaker setup selected to NONE?	• Properly connect it. • Press Mute button to cancel the function. • Adjust the volume. • Refer to pages 20~21 to select LARGE, SMALL or YES.
Picture does not appear when the function is selected.	• Isn't the external component connected properly?	• Properly connect it.
Remote controller does not work.	• Are the batteries exhausted? • Is the distance between remote control and main unit proper?	• Replace with new batteries. • Operate at close distance.
The sound from each device is changed during stereo playback.	• Is the left/right speaker or left/right input/output code connected properly?	• Check the left/right channel and properly connect it.
Can't receive broadcasting.	• Is AM or FM antenna connected properly?	• Properly connect the antenna. • If the input strength of antenna connector is weak, install the FM antenna in a place with good reception.
There is no sound from surround speaker.	• Is the surround speaker connected properly? • Is S.SPK (Surround) set to NONE in Speaker Setup? • Is Surround Mode selected to Stereo?	• Refer to pages 10~11 to connect it properly. • Refer to pages 20~21 to select LARGE or SMALL. • Refer to pages 30~37 to select other Surround Mode.
There is no sound from center speaker	• Is the center speaker connected properly? • Is C.SPK (Center) selected to NONE in Speaker Setup? • Is the Surround Mode selected to Stereo?	• Refer to pages 10~11 to connect it properly. • Refer to pages 20~21 to select LARGE or SMALL. • Refer to pages 30~37 to select other Surround Modes.

Symptom	Check	Remedy
Can't select Dolby Pro Logic II Mode.	• Is the input signal selected properly?	• Select 2 channel Dolby Digital, PCM, and Analog input signal.
There is no sound when playing DTS encoded DVD and CD.	• Is analog input selected?	• Check whether digital external component is properly connected and refer to page 22 to select the digital input.

Product Protection Function

Heat Protection

- Protection function works if the main unit is overheated or power transformer is overheated.
  "PROTECTION" appears in the display when this function works.
  - If speaker terminal is shorted
  - If speaker cord is shorted

  If there is no problem when you turn it on again after turning it off, PROTECTION mark will disappear on the display and the unit will work properly.

Note

- If PROTECTION appears on the display, check whether speaker terminal is shorted and then turn on the device.

Specifications

GENERAL	Power Supply	230V, 50 Hz
	Standby Power Consumption	0.9W
	Weight	4.0 kg
	Dimensions (W x H x D)	430 x 70x 360 mm
	Operating Temperature Range	+5°C~+35°C
	Operating Humidity Range	10%~75%
FM TUNER	Frequency Response	87.5~108.0MHz
	Usable Sensitivity	12dBf
	S/N Ratio	MONO/STEREO 55/55dB
	Distortion	MONO/STEREO 0.3/0.8%
	Stereo Separation	30dB
	Tuner Output Level	1KHz, 75KHz Dev
AM TUNER	Frequency Response	522~1611KHz
	S/N Ratio	40dB
	Usable Sensitivity	60dBμV/m(Loop Antenna)
	Distortion	2% (MOD:80%)
AMPLIFIER	Rated Output	20Hz~20KHz/THD = 10%
	Front Speaker(Left+Right)	4 Ω 100W/CH
	Center Speaker	4 Ω 100W/CH
	Surround Speaker(Left+Right)	4 Ω 100W/CH
	Subwoofer Speaker	4 Ω 100W/CH
	Input Sensitivity/Impedance	450mV/47kΩ
	S/N Ratio(Analog Input)	80dB
	Separation(1KHz)	60dB
FREQUENCY RESPONSE	Analog Input	20Hz~20KHz(±3dB)
	Digital Input	20Hz ~44KHz(±3dB)
VIDEO OUTPUT	TV Format	NTSC/PAL
	Input Level/Impedance	1Vp-p/75 Ω
	Output Level/Impedance	1Vp-p/75 Ω
	Video Frequency Response	5Hz to 10KHz(-3dB)
	Component Video Frequency Response	5Hz to 40KHz(-3dB)
	S/N Ratio	60dB

※ S/N ratio, distortion, separation and usable sensitivity are based on measurement using AES-17 filter.

SPEAKERS	Speaker system	Front / Surround	Center	Subwoofer speaker
	Impedance	4Ω x 4	4Ω	4Ω
	Rated output	100W	100W	100W
	Maximum output	200W	200W	200W
	Dimensions (W x H x D)	90 x 152 x 90 mm	200 x 90 x 92 mm	175 x 320 x 381 mm
	Weight	0.58 Kg/0.51Kg	0.64 Kg	5 Kg

Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Region	Country	Customer Care Center ☎	Web Site
North America	CANADA	1-800-SAMSUNG (7267864)	www.samsung.com/ca
	MEXICO	01-800-SAMSUNG (7267864)	www.samsung.com/mx
	U.S.A	1-800-SAMSUNG (7267864)	www.samsung.com
Latin America	ARGENTINE	0800-333-3733	www.samsung.com/ar
	BRAZIL	0800-124-421	www.samsung.com/br
	CHILE	800-726-7864(SAMSUNG)	www.samsung.com/cl
	COSTA RICA	0-800-507-7267	www.samsung.com/latin
	ECUADOR	1-800-10-7267	www.samsung.com/latin
	EL SALVADOR	800-6225	www.samsung.com/latin
	GUATEMALA	1-800-299-0013	www.samsung.com/latin
	JAMAICA	1-800-234-7267	www.samsung.com/latin
	PANAMA	800-7267	www.samsung.com/latin
	PUERTO RICO	1-800-682-3180	www.samsung.com/latin
	REP. DOMINICA	1-800-751-2676	www.samsung.com/latin
	TRINIDAD & TOBAGO	1-800-7267-864	www.samsung.com/latin
	VENEZUELA	1-800-100-5303	www.samsung.com/latin
Europe	BELGIUM	02 201 2418	www.samsung.com/be
	CZECH REPUBLIC	844 000 844	www.samsung.com/cz
	DENMARK	38 322 887	www.samsung.com/dk
	FINLAND	09 693 79 554	www.samsung.com/fi
	FRANCE	08 25 08 65 65 (0,15€/Min)	www.samsung.com/fr
	GERMANY	01805 - 121213 (€ 0,12/Min)	www.samsung.de
	HUNGARY	06 40 985 985	www.samsung.com/hu
	ITALIA	199 153 153	www.samsung.com/it
	LUXEMBURG	02 261 03 710	www.samsung.lu
	NETHERLANDS	0900 20 200 88 (€ 0.10/Min)	www.samsung.com/nl
	NORWAY	231 627 22	www.samsung.com/no
	POLAND	0 801 801 881	www.samsung.com/pl
	PORTUGAL	80 8 200 128	www.samsung.com/pt
	SLOVAKIA	0850 123 989	www.samsung.com/sk
	SPAIN	902 10 11 30	www.samsung.com/es
	SWEDEN	08 585 367 87	www.samsung.com/se
	U.K	0870 242 0303	www.samsung.com/uk
CIS	RUSSIA	8-800-200-0400	www.samsung.ru
	UKRAINE	8-800-502-0000	www.samsung.com/ur
Asia Pacific	AUSTRALIA	1300 362 603	www.samsung.com/au
	CHINA	800-810-5858, 010- 6475 1880	www.samsung.com.cn
	HONG KONG	2862 6001	www.samsung.com/hk
	INDIA	3030 8282 1600 1100 11	www.samsung.com/in
	INDONESIA	0800-112-8888	www.samsung.com/id
	JAPAN	0120-327-527	www.samsung.com/jp
	MALAYSIA	1800-88-9999	www.samsung.com/my
	PHILIPPINES	1800-10-SAMSUNG (7267864)	www.samsung.com/ph
	SINGAPORE	1800-SAMSUNG (7267864)	www.samsung.com/sg
	THAILAND	1800-29-3232 02-689-3232	www.samsung.com/th
Middle East & Africa	TAIWAN	0800-329-999	www.samsung.com/tw
	VIETNAM	1 800 588 889	www.samsung.com/vn
	SOUTH AFRICA	0860 7267864 (SAMSUNG)	www.samsung.com/za
	U.A.E	800SAMSUNG (7267864)	www.samsung.com/mea